

<i>Iron 1</i>	
Volume Desired (Stock Solutions):	1.00 L
Shelf Life (Stock):	3.00 months
Capacity:	<i>variable</i>
pH:	~ acidic
Type:	Toner, Direct
<i>Stock Solution A</i>	
Water	150.00 ml
Ferric Ammonium Citrate	5.00 g
Sulphuric Acid, Concentrated	20.00 ml
Water to make	250.00 ml
<i>Stock Solution B</i>	
Water	150.00 ml
Potassium Ferricyanide	5.00 g
Water to make	250.00 ml

Notes:

To create a working solution, combine 1 part A with 1 part B with 10-40 parts water (depending on desired strength).